Know the material.
Care for the product.

Bamboo

Frames, shelves, furniture and kitchen organizers.

EVERYDAY CARE

Wipe with a soft cloth, lightly dampened when needed, then dry promptly. Remove spills without delay.

AVOID

Do not soak or put in a dishwasher. Avoid prolonged dampness, direct heat and strong sunlight.

MDF panels

Shelf panels, cabinet parts and tabletops, combined with bamboo.

EVERYDAY CARE

Dust gently and use only a slightly damp cloth on finished surfaces. Dry edges and joints immediately.

AVOID

Avoid standing water, steam, abrasive pads and heavy impacts at panel edges.

Synthetic rattan

Woven-look inserts in cabinets, baskets and furniture.

EVERYDAY CARE

Use a soft brush or low-suction vacuum to remove dust from the weave. Spot-clean gently and dry.

AVOID

Avoid sharp tools, forceful scrubbing and high heat. A woven finish does not imply outdoor weather resistance.

Know the material.
Care for the product.

Oxford & cationic fabrics

Laundry baskets, organizers and selected outdoor seating.

EVERYDAY CARE

Brush off loose dust and spot-clean with mild soap and a damp cloth. Test on a hidden area first and air-dry fully.

AVOID

Do not machine-wash, bleach or tumble-dry unless the specific fabric label permits it.

Canvas & cotton-linen blends

Selected storage baskets and outdoor seating.

EVERYDAY CARE

Spot-clean small marks gently, following any model-specific care label. Dry completely before folding or storing.

AVOID

Avoid soaking assembled products and storing fabric while damp. Do not assume removable fabric is machine-washable.

Acrylic

Transparent doors and display components.

EVERYDAY CARE

Remove dust with a soft, clean microfiber cloth. If needed, use mild soapy water and dry with a soft cloth.

AVOID

Avoid abrasive cleaners, rough cloths, alcohol, acetone and ammonia-based glass cleaners.

Know the material.
Care for the product.

Metal & hardware

Carbon-steel components, fittings, hinges and caster wheels.

EVERYDAY CARE

Keep dry, wipe away dirt and check fasteners and moving parts periodically. Follow the assembly instructions for tightening.

AVOID

Avoid corrosive cleaners and prolonged moisture. Do not exceed the confirmed load rating.

Fabric & foam padding

Cushioned benches and other upholstered components.

EVERYDAY CARE

Vacuum gently and spot-clean the fabric surface. Use minimal moisture and let it dry thoroughly.

AVOID

Avoid saturating the foam, high heat and chemical solvents. Follow any attached upholstery care label.

Before using or storing your product

Clean gently. Dry promptly. Store dry and sheltered. Match the assembly guide to your model and periodically check fittings and moving parts.

General material guidance only. Your product care label, surface finish and model-specific instructions take priority. Outdoor category placement does not establish continuous weather resistance. Ask our team about load limits, food-contact use and exposure requirements for your selected model.